



Technical Data

To determine the load capacity of a cantilever construction, please add the permissible load of the bracket with the permissible loads mentioned in the table "Socket Angle".

